

Parts List

Item No.	Description	Part No.	Qty
1	Motor kit	As arranged	1
2	Motor support rack kit	880688	1
3	Drum kit	880689	1
4	Connect shaft kit	880690	1
5	Tie bar kit	880691	4
6	Gearbox support rack kit	880692	1
7	3 rd stage carrier kit	881623	1
8	2 nd stage carrier kit	881624	1
9	3 rd ring gear kit	880697	1
10	Fix plate kit	880698	1
11	1 st stage carrier kit	881625	1
12	1 st & 2 nd ring gear kit	880664	1
13	1 st shaft kit	880700	1
14	Brake base kit	880701	1
15	Brake kit	As arranged	1
15-1	Brake disc	880702	2
15-2	Brake coil	As arranged	1
16	Brake rear cover kit	880703	1
17	Wire rope w/hook	880704	1
18	Low voltage control ass'y LV-360	As arranged	1
18-1	Remote control,PB-306	881048	1
19	Base plate kit	880706	1

Part No. configurations:

Cycle	Voltage	kw x p	Motor
60 Hz	440 V	11 x 4	882802
50 Hz	380 V	11 x 4	880709
50 Hz	415 V	11 x 4	880710
60 Hz	208 V	11 x 4	882172

Cycle	Voltage	Brake kit	Brake coil	LV-360
60 Hz	440 V	880718	880722	882803
50 Hz	380 V	880716	880720	881855
50 Hz	415 V	880717	880721	881856
60 Hz	208 V	882174	882175	882173

Standard Value for brake coil :

Voltage	208V/220V	380V	415V	440V
Black & Blue wires	9Ω	27Ω	34Ω	41Ω
Black & Red wires	4Ω	17Ω	18Ω	18Ω
Red & Blue wires	5Ω	15Ω	19Ω	23Ω

Winch Assembly

